



1. Insert the plug of the power adapter into the socket **(6)** on the TA74. Feed the cord through the cable channel and through the opening on the back of the unit.
2. Plug the power adapter into the power outlet.