



1. Insert the plug of the network connection cable into the socket **(3)** on the TA74. Feed the cord through the cable channel and through the opening on the back of the unit.
2. According to your installation, fit the other end of the network connection cable into your router outlet or switch.