



1. Insert the plug of the telephone cable into the socket **(1)** on the TA74. Feed the cord through the cable channel and through the opening on the back of the unit.
2. Fit the plug of the telephone cable into the socket of the telephone outlet.