



1. Insert the plug of the power adapter into the socket **(6)** on the TA74. Feed the cord through the cable channel and through the opening on the back of the unit.
2. Plug the power adapter into the power outlet.

All the indicator lights will illuminate up for approx. 2 seconds, this is a battery test. The unit enters into standby mode and can now be programmed (refer to the *Reference Manual* for more information on programming).

---

### **INFO**

The backup battery will charge up when the TA74 is connected to the main power supply. The specified standby time is available when the battery is fully charged, after approx. 16 hours.

If the unit is disconnected and stored, connect it to the main power supply at least once every 6 months, to allow the battery to charge.

---